



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder/equipment is to be attached after the mount is in place. This mount consists of two parts: a mounting plate and an attaching piece.



1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover on the attaching piece. Hook the angled edge of the attaching piece over the center frame of the air vent.



2. Peel off the cover of the adhesive tape on the mounting plate. Place the mounting plate onto the attaching piece so the holes match. Attach the parts together by using the enclosed screws. Adjust the position and tighten the screws so the mount sits firmly in place.



3. The mount can be placed anywhere within the width of the air vent.

4. The ProClip mount is in place.

Az alábbiakkal kompatibilis

- Kia EV3 (2025-2026)