



# TELEPÍTÉS

## ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder/equipment is to be attached after the mount is in place.



1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Hook the angled upper edge of the mount over the air vent frame.



2. Pull the mount downward and hook the angled lower edge into the gap underneath the dashboard. Press upward so the edge sits properly in place.



3. This mount can be installed anywhere within the width of the air vent.

4. The ProClip mount is in place.

## Az alábbiakkal kompatibilis

- Kia EV4 (2025-2026)