



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder/equipment is to be attached after the mount is in place.



1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Hook the angled upper part of the mount into the gap between the air vent housing and the dashboard.



2. Press the lower edge of the mount upward and forward. Hook the angled lower edge of the mount into the gap between the air vent housing and the surrounding frame.



3. The mount can be placed as desired within the width of the air vents.

4. The ProClip mount is in place.

Az alábbiakkal kompatibilis

- Volkswagen T-Roc (2026)