



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder/equipment is to be attached after the mount is in place.



1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Press the angled lower edge of the mount into the gap between the frame surrounding the center console and the panel.



2. Pull the upper part of the mount upwards and hook the angled upper edge into the gap between the air vent frame and the panel.

3. The mount can be placed as desired within the width of the center console.



4. The ProClip mount is in place.

Az alábbiakkal kompatibilis

- BMW iX3 (2026)