



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder/equipment is to be attached after the mount is in place.



1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Press the angled edge on the upper part of the mount into the gap underneath the frame surrounding the upper section of the center console.



2. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the control panel and the dashboard, to widen the gap. Press the lower part of the mount downward/forward and hook the angled edge into the gap next to the gap opener. Pull out the gap opener.



3. The mount can be installed as desired within the width of the control panel.

4. The ProClip mount is in place.

Az alábbiakkal kompatibilis

- Mercedes Benz Vito (2024-2026)