



# TELEPÍTÉS

## ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder/equipment is to be attached after the mount is in place.



1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Hook the angled upper part of the mount into the gap between the trim and the panel surrounding the air vents.



2. Press the lower part of the mount upward and forward. Hook the angled edge over the frame surrounding the air vent.

3. The mount can be placed anywhere within the width of the air vents.



4. The ProClip mount is in place.

## Az alábbiakkal kompatibilis

- Mercedes Benz CLA-Class (2026); Mercedes Benz GLB-Class (2027)