



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder/equipment is to be attached after the mount is in place.



1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Hook the grooved lower edge of the mount into the gap between the air vent housing and the surrounding frame.



2. Press forward on the upper part of the mount so the grooved lower edge hooks into the gap between the air vent housing and the surrounding frame.

3. The mount can be attached to either side of the air vent.



4. The ProClip mount is in place.

Az alábbiakkal kompatibilis

- Holden Frontera (2024-2026)
- Opel Frontera (2024-2026)
- Vauxhall Frontera (2024-2026)