



TELEPÍTÉS

ProClip



Please read all instructions and review the pictures before installing the ProClip mount. Important: The mount must be installed before attaching any device holder, cradle, or other accessory.



1. Clean the installation area using the enclosed alcohol wipe. Remove the protective liner from the double-sided adhesive tape. Press the angled edge on the lower part of the mount into the gap between the air vent housing and the surrounding frame.



2. Press the upper part of the mount downward and forward. Press forward on the upper part so the angled edge hooks into the gap between the air vent housing and the surrounding frame.

3. The mount can be placed as desired within the width of the air vents.



4. The ProClip mount is in place.

Az alábbiakkal kompatibilis

- Cupra Raval (2027)