



TELEPÍTÉS

ProClip



Please read all instructions and review the pictures before installing the ProClip mount. Important: The mount must be installed before attaching any device holder, cradle, or other accessory.



1. Clean the installation area using the enclosed alcohol wipe. Remove the protective liner from the double-sided adhesive tape. Hook the lower edge of the mount over the frame surrounding the air vent housing.



2. Press the upper part of the mount downward and forward. Press the upper part forward so that the angled upper edge hooks under the frame surrounding the air vent housing.

3. The mount can be positioned anywhere within the width of the air vents.



4. The ProClip mount is in place

Az alábbiakkal kompatibilis

- Volkswagen ID.3 Neo (2027)