



TELEPÍTÉS

ProClip



Please read all instructions and study the pictures before installing the ProClip mount. Important: The mount must be installed before attaching any device holder or other accessory.



1. Clean the installation area using the enclosed alcohol wipe. Remove the protective liner from the double-sided adhesive tape. Position the grooved lower edge of the mount on the frame surrounding the air vent.



2. Press the upper part of the mount downwards and forwards. Hook the grooved upper edge under the frame surrounding the air vent.

3. The mount can be positioned anywhere along the width of the air vent.

4. The ProClip mount is in place.



Az alábbiakkal kompatibilis

- Volkswagen ID. Polo (2027)