



TELEPÍTÉS

ProClip



Please read all instructions and study the pictures before installing the ProClip mount. Important: The mount must be installed before attaching any device holder or other accessory.



1. Clean the installation area using the enclosed alcohol wipe. Remove the protective liner from the double-sided adhesive tape. Hook the angled lower edge of the mount under the dashboard panel.



2. Press the upper part of the mount upwards and forwards. Hook the angled upper edge over the dashboard panel.

3. The mount can be positioned anywhere along the width of the screen.

4. The ProClip mount is in place.



Az alábbiakkal kompatibilis

- Skoda Epiq (2027)