



TELEPÍTÉS

ProClip



Attention! Read all instructions before attaching the ProClip.

1. Press the long upper part of the ProClip into the gap between the dashboard and the frame surrounding the air vent. Press hard until you hear/feel it snap into place.



2. Press the lower part of the ProClip into the gap between the dashboard and the frame surrounding the air vent. Press until you hear/feel it snap into place.

3. The ProClip is in place.

4. The ProClip is in place.

Az alábbiakkal kompatibilis

- Ford Mondeo (2001-2007)

