



TELEPÍTÉS

ProClip



Attention! Please read all instructions and look at the pictures before attaching the ProClip.

1. Peel off the adhesive tape covers on the ProClip. Pull out the rubber. Hook the curved edge on the ProClip over the edge of the dashboard.



2. Press forwards on the ProClip so the angled edge hooks behind the edge of the dashboard.

3. The ProClip is in place.

4. The ProClip is in place.

Az alábbiakkal kompatibilis

- Volvo FH series (2003-2006); Volvo FM series (2003-2006); Volvo NH series (2003-2006)

