



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the cover of adhesive tape on the ProClip. Hold the ProClip in an almost 90 degree position and press the curved edge into the gap between the dashboard top and the speaker cover.



2. Flip the ProClip downward, towards the air vent, so the curved edge hooks underneath the dashboard top.

3. The ProClip is in place.

4. The ProClip is in place.

Az alábbiakkal kompatibilis

- Infiniti EX35 (2008-2013)

