



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Place the grooved edge on the lower part of the ProClip over the frame surrounding the air vent.



2. Press the upper part of the ProClip downward and forward. Hook the grooved edge on the upper part of the ProClip under the frame surrounding the air vent.

3. Press on the ProClip so it is properly in place.



4. The ProClip is in place.

Az alábbiakkal kompatibilis

- Citroen Berlingo III (2019-2026); Citroen E-Berlingo (2025-2026)
- Fiat Doblò (2023-2026); Fiat E-Doblò (2025-2026)
- Opel Combo (2019-2026); Opel Combo Cargo Electric (2025-2026); Opel Combo e (2025-2026)
- Peugeot E-Rifter (2025-2026); Peugeot Partner (2019-2026); Peugeot Rifter (2019-2026)
- Toyota Proace City (2020-2026); Toyota Proace City Verso (2020-2026)

