

TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder/equipment is to be attached after the ProClip is in place.

1. Pull out the rubber sealant on the A-post slightly to widen the gap. Press the angled edge on the lower part of the ProClip into the gap.



2. Hook the edge around the A-post.

3. Press the upper part of the ProClip upward/forward so the angled edge hooks around the A-post.

4. The ProClip is in place.



Az alábbiakkal kompatibilis

- Toyota RAV 4 (2019-2025)
- Suzuki Across (2021-2026)

