



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder/equipment is to be attached after the mount is in place. This mount consists of two parts: a mounting plate and a support piece.



1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover on the support piece. Press the angled edge on the support piece into the gap between the panel frame surrounding the air vent and the dashboard. Press the support piece downward and forward so the edge goes all the way into the gap.



2. Press the thin end of the enclosed gap opener into the gap between the trim and the panel, to widen the gap. Peel off the adhesive tape cover on the mounting plate. Press the lower edge of the mounting plate into the gap next to the gap opener.



3. Press the upper part of the mounting plate downward and flip it forward, so the lower edge hooks into the gap and the holes in the upper part align with the holes in the attaching piece. Pull out the gap opener. Use the enclosed screws and attach the two parts together so the mount sits firmly in place.

4. The ProClip mount is in place.

Az alábbiakkal kompatibilis

- Volkswagen Passat (2024-2026)