



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder/equipment is to be attached after the mount is in place.



1. Press the angled lower edge of the mount diagonally forward/upward into the gap between the padded panel and the lower section of the dashboard.

2. Pull the mount upward and away from the padded panel. Keep the edge away from the padded panel and hook the angled upper edge into the gap between the padded panel and the air vent housing.



3. Press down on top of the mount so the angled edge goes all the way into the gap.

4. The ProClip mount is in place.



Az alábbiakkal kompatibilis

- Polestar 4 (2024-2026)