



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder/equipment is to be attached after the mount is in place.



1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Press the upper edge of the mount into the seam between the air vent housing and the surrounding frame.



2. Press the thin end of the enclosed gap opener into the gap between the air vent housing and the surrounding frame. Press lower part of the mount upward and insert the lower edge into the gap next to the gap opener. Press on each edge on the inside of the mount so they are fully seated into the gaps. Pull out the gap opener.

3. The mount can be installed on the passenger side air vent.



4. The ProClip mount is in place.

Az alábbiakkal kompatibilis

- Subaru Forester (2026)