



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the cover of adhesive tape on the ProClip. Hook and slide the angled edge under the console edge by the carpet.



2. Hook and slide the angled edge under the console edge by the carpet.

3. Press the thin end of the enclosed gap opener into the gap between center console and the console edge, to widen the gap. Place your index fingers under the ProClip and pull upwards and hook the angled edge over the console edge and into the gap next to the gap opener. Pull out the gap opener.



4. The ProClip is in place.

Az alábbiakkal kompatibilis

- Chevrolet Avalanche (2007-2010); Chevrolet Pickup (2007-2010); Chevrolet Silverado (2007-2010); Chevrolet Suburban (2007-2014); Chevrolet Tahoe (2007-2014)
- GMC Sierra (2007-2010); GMC Sierra Denali (2007-2010); GMC Yukon (2007-2014); GMC Yukon Denali (2007-2014); GMC Yukon XL (2007-2014); GMC Yukon XL Denali (2007-2014)

