



TELEPÍTÉS

ProClip



Please read the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Place the angled left side of the ProClip over the upper console edge.



2. Press firmly down on the right side of the ProClip so the angled edge flexes downward and hooks under and around the lower console sidewall edge.

3. The ProClip is in place.

4. The ProClip is in place.



Az alábbiakkal kompatibilis

- Nissan Pathfinder (2013-2021)

