



TELEPÍTÉS

ProClip



Please read the instructions and look at the pictures before installing the ProClip. Note: You can place the mount within the length of the console sidewall regardless of where the cup holder is placed.



1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Place the angled edge on the left side of the ProClip over the console edge.

2. Press firmly down on the right side of the ProClip so it flexes down and the angled edge hooks into the gap in the sidewall.

3. The ProClip is in place.

4. The ProClip is in place.



Az alábbiakkal kompatibilis

- Chevrolet Silverado 1500 Series (2014-2018); Chevrolet Silverado 2500/3500 Series (2015-2019)
- GMC Sierra 1500 Series (2014-2018); GMC Sierra 2500/3500 Series (2015-2019)

