



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before installing the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape cover on the ProClip. Press the angled edge on the left side of the ProClip into the gap between the console edge and the center console panel.



2. Press the thin end of the enclosed gap opener into the gap between the console edge and the carpet next to the ProClip, to widen the gap. Press down on the top of the ProClip so it flexes downward and the angled edge on the lower part of the ProClip hooks around the console edge by the carpet. Remove the gap opener.



3. The ProClip is in place

4. The ProClip is in place.

Az alábbiakkal kompatibilis

- Hyundai Genesis (2015-2020)

