



TELEPÍTÉS

ProClip



Please read the instructions and look at the pictures before installing the ProClip.

1. Open the compartment door. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Place the angled edge on the right side of the ProClip over the console edge.



2. Press firmly down on top of the ProClip so the angled lower edge hooks around the panel in the console sidewall. Close the compartment door. Note, the door opens and closes freely when the mount is attached.

3. The ProClip is in place.

4. The ProClip is in place.



Az alábbiakkal kompatibilis

- Chevrolet Suburban (2015-2020); Chevrolet Tahoe (2015-2020)
- GMC Yukon (2015-2020); GMC Yukon Denali (2015-2020); GMC Yukon XL (2015-2020); GMC Yukon XL Denali (2015-2020)

