



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before installing the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape cover on the ProClip. Hook the angled left edge of the ProClip around the edge of the right console side panel.



2. Press downward on the right side of the ProClip until the angled right edge hooks behind the lower edge of the right side of the console side panel.

3. The ProClip is installed.

4. The ProClip is installed.



Az alábbiakkal kompatibilis

- Nissan Altima (2016-2018)

