



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before installing the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape cover on the ProClip. Press the angled left edge of the ProClip into the gap between the frame surrounding the gear shift and the center console panel.



2. Press the right side of the ProClip downward so the angled right edge hooks under the lower section of the center console sidewall.

3. The ProClip is in place.



4. The ProClip is in place.

Az alábbiakkal kompatibilis

- Lexus LX Series (2016-2021)

