



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Press the thin right edge on the upper part of the ProClip into the gap between the trim and the padded floor console sidewall.



2. Press downward on the left side of the ProClip. At the same time, press the lower edge of the ProClip toward the floor console. Hook the left lower edge of the ProClip under the padded floor console sidewall.

3. The ProClip is in place



4. The ProClip is in place.

Az alábbiakkal kompatibilis

- Acura RDX (2019-2022)

