



# TELEPÍTÉS

## ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Insert the thin left edge of the ProClip into the seam between the cup holder and the top frame around the cup holder.



2. Press the ProClip to the left and insert the thin right edge of the ProClip into the seam between the cup holder and the top frame around the cup holder.

3. The ProClip is in place.

4. The ProClip is in place.



## Az alábbiakkal kompatibilis

- Cadillac XT4 (2019-2023)

