



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder/equipment is to be attached after the ProClip is in place.



1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Hook the left lower edge of the ProClip into the gap in the console side wall.



2. Press the ProClip rightwards until the thin right edge goes into the gap on the top of the console, between the black and chrome panels.

3. The ProClip is in place.

4. The ProClip is in place.



Az alábbiakkal kompatibilis

- Audi Q7 (2020-2026)