



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder/equipment is to be attached after the ProClip is in place.



1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Place the angled edge on the upper part of the ProClip over the center console frame.

2. Press downward on the left part of the ProClip and hook the J-shaped lower edge hooks under the center console side wall.



3. The ProClip is in place.

4. The ProClip is in place.



Az alábbiakkal kompatibilis

- Ford Explorer (2020-2024)