



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder/equipment is to be attached after the mount is in place. This mount consists of two parts: A mount and a faceplate.



1. Hook the upper edge of the mount over the console frame.

2. Align the lower edge with the gap in the bottom console seam. Press downward on the right side of the mount and press the lower part toward the console sidewall so the edge hooks into the gap.



3. Place the faceplate onto the mount and angle it as desired. Align the screw holes and secure the faceplate to the mount using the included screws.

4. The ProClip mount is in place.

Az alábbiakkal kompatibilis

- Hyundai Santa Fe (2024-2026)

