

TELEPÍTÉS

ProClip





Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder/equipment is to be attached after the mount is in place. This mount consists of two parts: A mount and a faceplate.



1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Press the thin ends of the included gap openers into the gap between the center console sidewall and the top panel, to widen the gap. Peel off the adhesive tape cover. Press the upper edge of the mount into the gap between the gap openers. Pull out the gap openers.





bottom of the mount until the lower edge snaps/clips under the console sidewall.

2. Press down on the top of the mount and in on the



- 3. Place the included locking washer into the recess on top of the mount. Place the faceplate onto the mount. Adjust the faceplate into the desired angle. The faceplate may be installed for use by the driver or passenger. Attach the faceplate to the mount with the included screw.
- 4. The ProClip mount is in place.

Az alábbiakkal kompatibilis

• Ford Ranger (2019-2023)