



TELEPÍTÉS

ProClip



Attention! Read all instructions before attaching the ProClip.

The ProClip can be placed anywhere within the width of the air vents.

1. Press the upper part of the ProClip into the gap between the frame surrounding the air vents and the dashboard.



2. Press the upper part of the ProClip into the gap between the frame surrounding the air vents and the dashboard.

3. Hook the lower part of the ProClip over the frame surrounding the air vents.



4. The ProClip is in place.

Az alábbiakkal kompatibilis

- Citroen C8 (2002-2011)
- Peugeot 807 (2002-2010)
- Fiat Ulysse II (2002-2011)
- Lancia Phedra (2002-2011)

