



# TELEPÍTÉS

## ProClip



Attention! Read all instructions before attaching the ProClip.

Peel off the cover of the adhesive tape on the ProClip.

1. Press the thin edge on the left side of the ProClip into the gap between the panel frame surrounding the stereo and the padded part of the dashboard.



2. Press forward on the right side of the ProClip, towards the dashboard, so the angled edge snaps over the panel frame surrounding the air vent.

3. Press on the ProClip so it is properly in place.

4. The ProClip is in place.



## Az alábbiakkal kompatibilis

- Dodge Ram Pick Up 1500 (2002-2005); Dodge Ram Pick Up 2500/3500 (2003-2005)

