



TELEPÍTÉS

ProClip



Attention! Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the grooved edge on the lower part of the ProClip into the gap between the frame surrounding the air vent and the dashboard,



2. Hook/Press the grooved edge on the upper part of the ProClip into the gap between the frame surrounding the air vent and the dashboard.

3. Press on the ProClip so it is properly in place.

4. The ProClip is in place.

Az alábbiakkal kompatibilis

- Volvo V70 N (2000-2008); Volvo XC70 (2000-2007)

