



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the cover of adhesive tape on the ProClip. Hook the angled edge on the upper part of the ProClip into the gap between the two panel sections on the dashboard.



2. Hook the angled edge on the upper part of the ProClip into the gap between the two panel sections on the dashboard.

3. Press down on top of the ProClip so the angled edge on the lower part of the ProClip hooks under the panel frame edge by the air vent.

4. The ProClip is in place.



Az alábbiakkal kompatibilis

- Ford Excursion (2005-2007); Ford F-Series 250 (2005-2007); Ford F-Series 350 (2005-2007); Ford F-Series 450 (2005-2007); Ford F-Series 550 (2005-2007); Ford F-Series 650 (2005-2007); Ford F-Series 750 (2005-2007)

