



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap openers into the gap between the control panel and the surrounding frame, to widen the gap. Peel off the adhesive tape covers on the ProClip. Press the angled edge on the right part of the ProClip into the gap between the gap openers. Pull out the gap openers.



2. Press the gap openers into the gap between the frame surrounding the control panel and the dashboard. Press forward on the left side of the ProClip so the angled edge hooks into the gap between the gap openers.



3. Press on the ProClip so it is properly in place. Pull out the gap openers.

4. The ProClip is in place.

Az alábbiakkal kompatibilis

- Chevrolet Captiva (2007-2011)

