



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the cover of adhesive tape on the ProClip. Hook the angled edge on the lower part of the ProClip around the upper air vent edge.



2. Press firmly forward on the upper part of the ProClip so the angled edge goes into the gap between the dashboard and the top part of the center console.

3. Press until you see or hear/feel it snaps into place.

4. The ProClip is in place.

Az alábbiakkal kompatibilis

- Cadillac SRX (2007-2009)

