



TELEPÍTÉS

ProClip



Please read the instructions and look at the pictures before attaching the ProClip. This ProClip can be placed anywhere within the width of the air vent.

1. A mellékelt alkoholos kendő segítségével tisztítsa meg azt a területet, ahová a ProClip kerülni fog. Peel of the adhesive tape covers on the ProClip. Press the angled edge on the lower part of the ProClip into the gap between the air vent and the surrounding frame.



2. Press downward on the lower part of the ProClip so the angled edge goes all the way into the gap.

3. Press the upper part of the ProClip downward, then press it forward and hook the angled edge under the frame surrounding the air vent.



4. The ProClip is in place.

Az alábbiakkal kompatibilis

- Toyota Auris (2013-2015); Toyota Auris Full Hybrid (2013-2015)

