



TELEPÍTÉS

ProClip



Please read the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the center console and the dashboard, to widen the gap. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape cover on the ProClip. Press/hook the upper edge of the ProClip into the gap next to the gap opener.



2. Pull the lower part of the ProClip toward you. Hook the lower edge of the ProClip under the frame surround the air vent.

3. Press on the ProClip so it is properly in place.



4. The ProClip is in place.

Az alábbiakkal kompatibilis

- Mitsubishi Mirage (2013-2024); Mitsubishi Space Star (2013-2024)

