



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Place the curved edge on the upper part of the ProClip against the upper part of the air vent frame.



2. Place your finger under the lower part of the ProClip and push up so the ProClip flexes upward. Then hook the lower edge of the ProClip over the lower air vent frame edge.

3. The ProClip is in place.

4. The ProClip is in place.



Az alábbiakkal kompatibilis

- Tesla Model S (2013-2020); Tesla Model X (2016-2020)

