



TELEPÍTÉS

ProClip



Please read the instructions and look at the pictures before installing the ProClip.

1. Press the thin angled edge on the upper part of the ProClip into the seam/gap between the air vent and the surrounding panel.



2. Push upward on the lower part of the ProClip so it flexes up and then hook the thin edge over the air vent panel edge.

3. The ProClip is in place.

4. The ProClip is in place.

Az alábbiakkal kompatibilis

- Kia Forte (2014-2018)

