



TELEPÍTÉS

ProClip



Please read the instructions and look at the pictures before installing the ProClip. This ProClip can be placed at desired position along the width of the panel.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape cover on the ProClip. Press the angled lower edge of the ProClip into the gap between the trim and the center console.



2. Push the top part of the ProClip upward/forward. Press the angled top part of the ProClip into the gap between the trim and the dashboard.

3. The ProClip is in place.

4. The ProClip is in place.



Az alábbiakkal kompatibilis

- BMW X5 (2014-2018); BMW X6 (2015-2019)

