



TELEPÍTÉS

ProClip



Please read the instructions and look at the pictures before installing the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the center console panel frame and the panel frame surrounding it, to widen the gap. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape cover on the ProClip. Press the angled edge on the lower part of the ProClip into the gap next to the gap opener.



2. Press firmly forward on the ProClip so it flexes forward and the angled edge hooks around the panel frame edge by the padded part of the dashboard. Pull out the gap opener.



3. The ProClip is in place.

4. The ProClip is in place.

Az alábbiakkal kompatibilis

- Chevrolet Silverado (2014-2018); Chevrolet Silverado 1500 Series (2014-2018); Chevrolet Silverado 2500/3500 Series (2015-2019)
- GMC Sierra 1500 Series (2014-2018); GMC Sierra 2500/3500 Series (2015-2019)

