



TELEPÍTÉS

ProClip



Please read the instructions and look at the pictures before installing the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the cover of adhesive tape on the ProClip. Press the thin edge on the lower part of the ProClip into the gap between the padded part of the dashboard and the silver trim.



2. Press the thin end of the enclosed gap opener into the gap between the padded dashboard sections, to widen the gap. Press firmly forward on the upper part of the ProClip so it flexes forward and the angled edge hooks into the gap next to the gap opener. Pull out the gap opener.



3. The ProClip is in place.

4. The ProClip is in place.

Az alábbiakkal kompatibilis

- Kia Optima (2016-2015)

