



TELEPÍTÉS

ProAdapt adapter



Please read all of the instructions and look at the pictures before installing the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape cover on the ProClip. Open the glove compartment. Hook the lower angled edge of the ProClip under the silver trim above the glove compartment opening.



2. Insert the grooved upper edge of the ProClip into the gap between the upper edge of the silver trim and the padded part of the dash. Press the ProClip forward until you hear/feel that the grooved edge snaps into place behind the panel.



3. The ProClip is in place.

4. The ProClip is in place.

Az alábbiakkal kompatibilis

- Acura ILX (2016-2018)

