



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before installing the ProClip.

1 Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape cover on the ProClip. Press the angled left edge of the ProClip into the gap between the frame surrounding the speedometer and the dashboard.



2. Push the ProClip rightward so the angled edge slides under the frame surrounding the speedometer. Hook the angled right edge of the ProClip around the left edge of the frame surrounding the air vent. Press on the ProClip to make sure the adhesive tape attaches properly.



3. The ProClip is in place.

4. The ProClip is in place.

Az alábbiakkal kompatibilis

- Dodge Ram Chassis Cab (2013-2018); Dodge Ram Pick Up 1500 (2013-2018); Dodge Ram Pick Up 2500/3500 (2013-2018); Dodge Ram Pick Up 4500/5500 (2013-2018)

