



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before installing the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape cover on the ProClip. Press the angled right edge of the ProClip into the gap between the air vent frame and the frame surrounding the storage cubby.



2. Move the ProClip leftward so the angled right edge hooks behind the storage cubby frame. Hook the angled left edge of the ProClip around the right edge of the air vent frame. Press the ProClip forward to make sure the adhesive tape attaches properly.



3. The ProClip is in place.

4. The ProClip is in place.

Az alábbiakkal kompatibilis

- Dodge Ram Chassis Cab (2013-2018); Dodge Ram Pick Up 1500 (2013-2018); Dodge Ram Pick Up 2500/3500 (2013-2018); Dodge Ram Pick Up 4500/5500 (2013-2018)

