



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before installing the ProClip.
This ProClip must be placed as shown in the pictures.



1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape cover on the ProClip. Align the left side of the upper edge of the ProClip with right side of the frame surrounding the hazard button. Place the upper edge of the ProClip onto the upper edge of the air vent.



2. Press upward on the lower part of the ProClip, flexing it, and hook the milled lower edge of the ProClip around the edge of the information screen.

3. The ProClip is in place.

4. The ProClip is in place.

Az alábbiakkal kompatibilis

- Honda Civic (2016-2021)

