



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before installing the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape cover on the ProClip. Hook the angled lower edge of the ProClip around the edge of the upper vent opening.



2. Push forward on the ProClip so it flexes and the angled upper edge hooks around the panel edge surrounding the information display. Press down on top of the ProClip to make sure the angled edge is properly hooked around the panel edge, and for best possible attachment of the adhesive tape.



3. The ProClip is in place.

4. The ProClip is in place.

Az alábbiakkal kompatibilis

- Honda Accord (2015-2017); Honda Accord Coupé (2015-2017)

